



GRAVOTECH

OPERATING AND MAINTENANCE MANUAL

Laser Workstation

LW2 Touch

MARKING LASER



GRAVOTECH

Type 3 

Technifor 

Gravograph 

Table of contents

A. Foreword	6
1. Appreciation	6
2. Information	6
B. Legal notices	7
C. Regulation observance	8
D. Required safety labels	9
E. Introduction	11
1. Presentation	11
2. Instructions for use and warranty limitations	11
3. Identification of the marking equipment	11
■ Description of symbols used (ID plate)	11
4. Work station safety	12
■ Control Unit / marking head	12
■ Door motorization	12
■ Handling the machine	12
F. Unpacking	13
1. Packaging	13
G. Laser safety	15
1. Recommendations and safety regarding laser devices	15
■ Personnel safety	15
2. Labels	16
■ Warranty labels	16
■ Glass protection index	16
3. Work station safety	17
■ General Instructions	18
■ Wearing safety glasses	18
4. Potential hazards related to materials worked with	19
■ Fumes and toxic particles	19
■ Examples of secondary radiation risks	20
■ Reflected beam	20
H. Description of the machine	21
■ Global view of the marking area	21

I. Color touch screen	22
1. Main screen	23
■ Main menu	23
■ Start marking	23
■ Stop marking	23
■ Door opening/closing	24
■ Z axis	24
■ Door opening/closing: Automatic mode	25
2. Marking parameters	26
■ Configuration: Command	26
■ Network configuration	27
■ Adjustment	28
■ System information	28
■ Update	29
3. "File" menu	32
■ Marking file	32
■ Logos	32
■ Fonts	33
■ USB connection	33
4. "Variables" menu	34
5. Menu: Security mode	34
■ "Supervisor" mode	34
■ "Operator" mode	36
■ Technician mode	39
6. Emergency stop	40
J. Installation	42
1. Electrical installation	42
2. Physical installation	42
■ Step 1: Opening the casing	42
■ Step 2	44
3. Fiber series (+ Energy)	44
■ Step 3	44
■ Step 4	46
■ Step 5: Optical head connection	47
■ Step 6: Connection of the marking head to the CCU	48
4. Hybrid - Green - CO2 Energy series	50
■ Step 3	50
■ Step 4	51

K. Connections - Installation	53
1. Connecting the Control Unit (Fiber series (+ Energy))	53
2. Installation	58
■ Possible integration and operating positions for the Fiber Series (+Energy)	58
■ Possible integration and operating positions for the Hybrid - Green - CO2 Energy Series	58
■ Laser startup	59
■ Emergency stop	59
L. Accessories available upon request	60
1. List of accessories and options available upon request	60
■ Rotary device	61
■ Work station safety	61
■ Other accessories	62
2. Wearing and spare parts	63
■ Spare parts	63
■ Wearing parts	63
M. Preventive maintenance	64
1. Visual inspection of the bellows (rear of LW2 Touch)	64
2. Every year	65
■ Cleaning the sensors	65
N. Dimensional drawings	66
1. LW2 Touch dimensional drawing	66
2. Fiber - Hybrid - Green - CO2 Energy Series	67
■ LW2 Touch dimensional drawing	67
■ Dimensional drawing of the table	68
3. Max height of the part to be marked	69
■ 100 Focal lens	69
■ 160 Focal lens	69
■ 254 Focal lens	69
■ 330 Focal lens	69
O. Noise emission of the machine	70
1. Test code	70
■ Measurement method	70
■ Material used for marking:	70
■ Definition of the microphone position	70
■ Test conditions	70
2. Noise emission information	70

P. Technical specifications71

- 1. Physical characteristics 71
- 2. Electrical characteristics 72
- 3. Environment 72
- 4. Laser beam 72
- 5. Aiming diode - Focusing diode 72
- 6. Material 73

A. Foreword

1. Appreciation

Thank you for choosing LW2 Touch - Gravotech.

Gravotech is pleased to count you among the users of its engraving and traceability solutions.

For help, contact Gravotech.

For more information on products, visit www.gravotech.com website.

2. Information



To ensure security and productivity, read this manual before starting-up the equipment. It provides details about the installation and use of the equipment.

Keep this manual in case you need to refer to it.



For the attention of users having an individual cardiac assist device fitted:

Our equipment is designed and manufactured with the greatest care in order to guarantee their compliance with the EMC Directive currently in force. This means that the levels of electromagnetic emissions produced by this equipment when in operation are limited and do not exceed the thresholds defined by the Directive.

However, multiple factors make it impossible to guarantee the total absence of risk for users having a cardiac assist device fitted. Consequently, it is recommended that standing for a prolonged period within less than 1 m (3.281 ft) of an operating machine should be avoided.

B. Legal notices

Last updated: 10/2015

The purpose of this document is to provide users (hereinafter the User(s)) with information and to ensure their safety. It has no contractual value and Gravotech group (hereinafter Gravotech) reserves the right, at any time and without notice, to make such changes or improvements as it deems fits, or to substitute any new equipment and/or material and/or part and/or image to its equipment, software and/or associated manuals or documentation (hereinafter the Product(s)).

This manual, including texts, images, photos, graphics, design, or any compilation, digital conversion or data contained in it, is subject to copyright. This manual shall not be reproduced, disseminated, transmitted, transcribed, translated or stored electronically, on any medium whatsoever regardless of its format without the express and written permission of Gravotech, to the exception of software backup copies as provided by law.

The intellectual property rights relating to the Products and to this manual, including - but not limited to - patents, trademarks, models, copyright, domain names and also the know-how, trading name or company name, are owned by Gravotech Marking S.A.S or any company of the Gravotech group. Under no circumstances does the transmission of this manual or the supply of Products or services constitute an assignment of or any express or tacit license for any intellectual property right owned by Gravotech.

To the extent permitted by law, Gravotech provides hereby no warranty (in particular no warranties of performance, non-infringement, merchantability or fitness for a particular purpose) relating to the supply of its Products, other than those conferred upon the User by Gravotech's general terms and conditions of sale or any contractual document agreed between Gravotech and the User. Nor does Gravotech guarantee the compatibility of its software with any software package not supplied by it, or any defect in assembly, adaptation, design, compatibility and operation with any or part of a combination created by the User.

Gravotech shall not be liable for any damages, that the User or its property, a third party or the Product itself may suffer, caused by the Product and arising from any inappropriate use or misuse of the Product, negligence, carelessness, inadequate supervision or maintenance, failure to observe the safety or usage instructions described herein or otherwise communicated to the User, the use of poor-quality or non-recommended lubricants, fluids and additives or where there is fault on the part of the User or a third party. As provided in this manual, the User shall furthermore (i) observe the normal conditions of use, (ii) not exceed the recommended maximum number of hours during which the equipment may be operated on and (iii) refrain from proceeding to any Product's repair or make it proceed by any unqualified third party, or without the appropriate personal protective equipment.

The Product's specifications are altered by (i) any Product's modification or alteration, (ii) any adaptation and installation of accessories that are not recommended by Gravotech, (iii) the integration of a control system and (iv) the connection to an external device. Such specifications' alterations may lead to the non-compliance of the Product with applicable rules and standards. Shall the Product be non-compliant, the person in charge of the Product's installation shall be responsible of the final workstation's compliance. In no event, Gravotech shall be liable for any damages arising from such non-recommended or unauthorized Product's alterations. It is precised that the warranty shall not apply in such case.

Under no circumstances shall Gravotech be held liable for any indirect, incidental, special, consequential punitive or other similar damages, including any economic loss, loss of profit, loss of data or opportunity, whether or not foreseeable by or communicated to Gravotech, caused by this manual or the supply of Products or services concerned by the said manual.

To the widest extent permitted by law, Gravotech shall only be held liable for direct damage arising from personal injury caused by a fault proven in its Product (including this manual).

Gravotech® - Type3® - Propen™ - Technifor™ - Gravograph® is (are) a used, pending or registered trademark(s) of Gravotech group or one of its subsidiaries.

The products and names of third party companies which appear in this manual are used solely for the necessary purposes of reference, and in particular for issues of compatibility. All the trademarks mentioned in this manual remain the property of their respective owners. Windows® is (are) a used, pending or registered trademark(s) of Microsoft Corporation. Postscript® is (are) a used, pending or registered trademark(s) of Adobe Systems Incorporated.

C. Regulation observance







Last updated: 01/2020

EC declaration of conformity or declaration of incorporation supplied with the machinery

































Type of machine	Directives - Standards
<p>Dot peen marking: Machine XF500p, XF500m, Impact p, Impact eZ p, Impact m, Impact eZ m P5000PN, P5000EM</p> <p>Scribing marking: Machine B-Engraver, M10, M10 Jewel, M20 Pix, M20 Energy RingCube, TagCube</p> <p>Sharpening by grinding: Machine CG30</p> <p>Bevelling: Machine B4, B6</p> <p>Engraving by milling: Machine IM3, IF3 M20, M20 Jewel, M20 ABC, M20 Pen, M20 Beauty Cube, M20 V3 M40, M40G, M40 ABC IS200, IS400, IS400 Volume IS6000, IS7000, IS8000 - XP - XP Milling</p> <p>Hot foil stamping: Machine M20 Artfoil</p> <p>Dot peen marking: Transportable machinery - Partly completed machinery XF530p, XF530m, XE320Cp, XM500</p> <p>Dot peen marking: Partly completed machinery XF510Cp-Sp-Dp, XF510Cm-Sm-Dm, XE310Cp-Sp</p> <p>Scribing marking: Partly completed machinery XF510Cr-Sr-Dr, SV510</p> <p>CCU, Rack, TouchPad UC500, UC500 SV, UC300, UC Laser, XCOM Racks IS</p> <p>Laser fume extractor ES10, ES20, ES30, ES40, ES50 LE120HP, LE140HP, LE150HP, LE190HP, LNI900</p> <p>Accessory: Partly completed machinery Rotary APF, Laser APF, Dotpeen APF PFD500 TAG3500 Cylinder attachment DMC15, DMC25, DMC25PN, DP3500, DP4500, DP4500PN RD1, RD2, RDM, RD Jewel eZ300</p>	<p>- Low voltage: 2014/35/EU - EMC: 2014/30/EU - RoHS 2: 2011/65/EU</p>
<p>Dot peen marking: Portable machine XM700</p>	<p>- Low voltage: 2014/35/EU - EMC: 2014/30/EU - RoHS 2: 2011/65/EU - Cells and batteries: 2006/66/EC</p>
<p>CO2, Yag and fiber laser marking: Machine (gantry) LS100 Energy, LS100 Ex Energy, LS900 Energy LS100, LS100 Ex, LS900, LS900 XP, LS1000XP LS100 Ex Fibre, LS900 Fibre LS900 Edge</p> <p>CO2, Yag and fiber laser marking: Machine (galvo) LW1, LW2, LW2 Touch, LW3, WeLase (Cxx, Fxx, Gxx, Hxx), WeLase 360 (Cxx, Fxx, Gxx, Hxx) Laser Solution Hybrid-Series (standard version, Version Energy), Laser Solution Green-Series (standard version, Version Energy), Laser Solution CO2-Series (standard version, Version Energy), Fiber Energy</p> <p>CO2, Yag and fiber laser marking: Partly completed machinery (galvo) – Class 4 Laser Solution Fiber-Series (standard version, Version Energy)</p>	<p>- Low voltage: 2014/35/EU - EMC: 2014/30/EU - RoHS 2: 2011/65/EU</p> <p>- Safety of laser products - Part 1: Equipment classification and requirements: EN 60825-1:2008 - Safety of laser products - Part 4: Laser guards: EN 60825-4+A1+A2:2006</p>

D. Required safety labels

Last updated: 01/2020

Machines concerned	Required safety labels																																
LS100 LS100 Ex LS100 Energy LS900 LS900 XP LS1000 XP LS100 Ex Fibre LS900 Fibre LS900 Edge WeLase	Shared labels																																
	<div><div> Warning: Laser beam</div><div> General warning</div><div> Warning: Flammable materials</div><div> Warning: Electricity</div><div> Warning: Crushing of hands</div><div> Refer to instructions manual/booklet.</div></div>																																
	<div><div><div>LASER RADIATION DO NOT STARE INTO BEAM. WAVELENGTH: 600-700 nm OUTPUT: 1 mW max CLASS 2M LASER PRODUCT <small>IEC 60825-1</small></div><div>THIS MACHINE HAS A CLASS 4 LASER BOXED IN A CLASS 1 CASING. THIS MACHINE IS CONSIDERED AS CLASS 2M DUE TO ITS VISIBLE LASER DIODE.</div><div>NEVER OPERATE THE LASER SYSTEM WITHOUT CONSTANT SUPERVISION. EXPOSURE TO THE LASER BEAM MAY CAUSE IGNITION OF COMBUSTIBLE MATERIALS WHICH CAN CAUSE SEVERE DAMAGE TO THE EQUIPMENT. TOXIC FUMES / PARTICLES MAY BE EMITTED BY THIS MACHINE.</div></div></div>																																
	"Passthrough" function																																
	LS100 LS100 Ex LS100 Energy LS900 LS900 XP LS1000 XP	LS100 Ex Fibre LS900 Fibre	LS900 Edge																														
	<div><div>AVOID EXPOSURE TO VISIBLE AND INVISIBLE LASER RADIATION EMITTED FROM THIS APERTURE.</div><div>CAUTION CLASS 4 VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION.</div><div>VISIBLE AND INVISIBLE LASER RADIATION AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION. CLASS 4 LASER PRODUCT <table><tr><td>LASER</td><td>PEAK POWER</td><td>WAVELENGTH</td><td>AVERAGE POWER</td><td>PULSE DURATION</td></tr><tr><td>LASER</td><td>/</td><td>8 - 11 µm</td><td><300W</td><td>/</td></tr></table></div></div>	LASER	PEAK POWER	WAVELENGTH	AVERAGE POWER	PULSE DURATION	LASER	/	8 - 11 µm	<300W	/	<div><div>AVOID EXPOSURE TO VISIBLE AND INVISIBLE LASER RADIATION EMITTED FROM THIS APERTURE.</div><div>CAUTION CLASS 4 VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION.</div><div>VISIBLE AND INVISIBLE LASER RADIATION AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION. CLASS 4 LASER PRODUCT <table><tr><td>LASER</td><td>PEAK POWER</td><td>WAVELENGTH</td><td>AVERAGE POWER</td><td>PULSE DURATION</td></tr><tr><td>LASER</td><td><100kW</td><td>1000-1300nm</td><td><120W</td><td>>1ns</td></tr></table></div></div>	LASER	PEAK POWER	WAVELENGTH	AVERAGE POWER	PULSE DURATION	LASER	<100kW	1000-1300nm	<120W	>1ns	<div><div>AVOID EXPOSURE TO VISIBLE AND INVISIBLE LASER RADIATION EMITTED FROM THIS APERTURE.</div><div>CAUTION CLASS 4 VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION.</div><div>VISIBLE AND INVISIBLE LASER RADIATION AVOID EYE OR SKIN EXPOSURE TO DIRECT OR SCATTERED RADIATION. CLASS 4 LASER PRODUCT <table><tr><td>LASER</td><td>PEAK POWER</td><td>WAVELENGTH</td><td>AVERAGE POWER</td><td>PULSE DURATION</td></tr><tr><td>LASER</td><td><100kW</td><td>1000-1300nm</td><td><120W</td><td>>1ns</td></tr></table></div></div>	LASER	PEAK POWER	WAVELENGTH	AVERAGE POWER	PULSE DURATION	LASER	<100kW	1000-1300nm	<120W	>1ns
	LASER	PEAK POWER	WAVELENGTH	AVERAGE POWER	PULSE DURATION																												
	LASER	/	8 - 11 µm	<300W	/																												
	LASER	PEAK POWER	WAVELENGTH	AVERAGE POWER	PULSE DURATION																												
	LASER	<100kW	1000-1300nm	<120W	>1ns																												
LASER	PEAK POWER	WAVELENGTH	AVERAGE POWER	PULSE DURATION																													
LASER	<100kW	1000-1300nm	<120W	>1ns																													

Required safety labels

Machines concerned	Required safety labels												
<p>Laser Solution Hybrid-Green-CO2 Series (standard version, version Energy)</p> <p>Laser Solution Fiber-Series (standard version, version Energy)</p>	<p>Shared labels</p> <div><div><p>Warning: Laser beam</p></div><div><p>General warning</p></div><div><p>Warning: Electricity</p></div><div><p>Refer to instructions manual/booklet.</p></div><div></div><div></div></div> <table><tr><th>Laser Solution Hybrid Series (standard version, version Energy)</th><th>Laser Solution Green Series (standard version, version Energy)</th><th>Laser Solution CO2 Series (standard version, version Energy)</th><th>Laser Solution Fiber-Series (standard version, version Energy)</th></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr></table>	Laser Solution Hybrid Series (standard version, version Energy)	Laser Solution Green Series (standard version, version Energy)	Laser Solution CO2 Series (standard version, version Energy)	Laser Solution Fiber-Series (standard version, version Energy)								
Laser Solution Hybrid Series (standard version, version Energy)	Laser Solution Green Series (standard version, version Energy)	Laser Solution CO2 Series (standard version, version Energy)	Laser Solution Fiber-Series (standard version, version Energy)										
													
													
<p>LW1 - LW2 - LW2 Touch - LW3</p>	<div><div><p>Warning: Laser beam</p></div><div><p>General warning</p></div><div><p>Warning: Flammable materials</p></div><div><p>Warning: Electricity</p></div><div><p>Warning: Crushing of hands</p></div><div><p>Refer to instructions manual/booklet.</p></div></div> <div></div> <div></div> <div></div> <div></div> <div></div>												

E. Introduction

1. Presentation

The LW2 Touch is a station allowing the attachment of a marking head. It is equipped with a motorized Z-axis mounted to a table.

Marking is carried out by the marking head, which integrates two motors (X- Y) to displace the laser beam on the part to mark.

2. Instructions for use and warranty limitations

The LW2 Touch machine is covered by a general 24-month warranty under normal conditions of use and maintenance. The warranty incorporates a limit of 750 000 usage cycles (Door opening/closing). The warranty expires when either of these conditions (period or number of cycles) is reached.






3. Identification of the marking equipment

The marking equipment is identified by:

- 1 identification plate on the rear face

Have the model and serial number of the equipment available when contacting Gravotech.

■ Description of symbols used (ID plate)

	<i>Alternating current</i>		<i>Fuse</i>
 	<i>The equipment must be disposed of at an appropriate collection point for processing, sorting, and recycling of Waste Electronic and Electrical Equipment (WEEE).</i> <i>By following these instructions, you are helping the environment, contributing to the preservation of our natural resources, and protecting human health.</i>		<i>Logo meets "EC" standard</i>

Introduction

4. Work station safety

- Turn off the machine before beginning any cleaning, maintenance or repair procedure.
- Never unplug a cable while the Control Unit is turned on.
- Use the appropriate protection when equipment is used in a polluted environment. Use of these protections are the user's or the integrator's responsibility.
- In the event of power problems, install a UPS (power conditioner).
- The marking head and the Control Unit must be clean and protected from dust. Exterior optics must be verified and cleaned if necessary.



Warning: Hazardous moving parts

■ Control Unit / marking head

For more information, consult the manual of the machine in question (Fiber - Hybrid - Green - CO2 Energy Series).

■ Door motorization

Manipulate the door with caution before switching on:

- 1. Remove the cover (See: Step 1: Opening the casing).**
- 2. Remove 2 screws in order to release the counterweights (See: Step 2).**


■ Handling the machine

- In the event of an extended period of non-use, unplug the power cable and protect the machine.
- Never pour or spill liquid on the machine (drinks, cleaning products, etc.) except where recommended by Gravotech.

Gravotech will not be held responsible for injuries resulting from disregard for the above operating instructions or other general safety rules applicable to the use of this equipment or resulting from misuse. Furthermore, disregard for the instructions will void the warranty.

F. Unpacking

1. Packaging






1. *Protective foam*
2. *Wedge*
3. *Contents of the box: screen + mounting bracket + cables*
4. *Box*
5. *Protective foam*
6. *LW2 Touch (maximum: 60 kg (132.277 lb))*
7. *Wedge*
8. *Pallet*

Unpacking



Unpack the machine with 3 operators.



1. LW2 Touch (weight: 60 kg (132.277 lb))
2. Unpack the machine with 3 operators.
3. Handles (x 6)

G. Laser safety

1. Recommendations and safety regarding laser devices

■ Personnel safety

THIS MACHINE HAS A CLASS 4 LASER BOXED IN A CLASS 1 CASING. THIS MACHINE IS CONSIDERED AS CLASS 2M DUE TO ITS VISIBLE LASER DIODE (RED).

- The machine is considered as Class 1 when the door is closed. In this case, the security enclosure of the LW2 Touch is locked and sealed against potential Laser radiation emissions under normal working and safety conditions. The modification of locking systems, or the removal of these systems or labels designed for safety, will result in exposure to hazards from the Laser beam. Any modification is prohibited. The LW2 Touch is closed, locked and labelled to ensure that it works in complete safety. The labels and security devices must not be removed or concealed by the operator.
- The machine is considered as Class 2M when the door is opened (emission power equal to or less than 1 mW). In this case, the security shutter in the Laser module closes to avoid any risk of Laser emission. The marking can only be carried out if the door is closed.

If the machine is being integrated, the installer is responsible for ensuring the final equipment conforms to current legislation. Observe EN 60825-1 standard concerning the controls and signage (access panels, doors, emergency stops...). Example: application of safety pictograms, installation of suitable guards, use of the electrical safety channel provided on the equipment (non-exhaustive list).

Only trained personnel aware of the risks posed by the machine are authorized to use it. Only Gravotech personnel, or persons authorized by Gravotech may service the elements that constitute the marking machine. Any intervention by unauthorized third party would exclude Gravotech's liability.

Laser radiation is invisible, but exposure, direct or scattered, is hazardous to skin and eyes.

Do not use this marking equipment in an explosive environment. No inflammable material should be located within the machine enclosure near the reflected beam (operator's shirt, curtains, wall covering in non-synthetic material: fire hazard). For safety reasons, never operate the machine without constant surveillance.

This equipment is not suitable for use in locations to which children have access.

This laser can produce dangerous diffuse reflections. It may lead to skin and eye injuries as well as a fire risk. Its use requires extreme caution. Fire prevention and protection equipment is the user's responsibility. Do not look at the Laser beam continuously when marking, even through the protective glass. The light intensity may strain the eye.

Laser safety

2. Labels

■ Warranty labels

These labels guarantee the laser was not opened or dismantled.

Opening without prior written consent voids warranty.

DO NOT OPEN LASER COVER
WARRANTY VOID IF
SEAL IS BROKEN *

** DO NOT OPEN THE LASER COVER
WARRANTY VOID IF SEAL IS BROKEN*

■ Glass protection index

940 nm -< 1150 nm DIR LB6 (OD6+): LW2 Touch + Fiber - Hybrid Energy Series

532 nm D LB5 + IR LB6: LW2 Touch + Green Energy Series

9000 nm -< 11000 nm D LB4: LW2 Touch + CO2 Energy Series

Laser safety

3. Work station safety

Specific hygiene and safety instructions

Personnel laser radiation protection

Concerned industrial use installation:

Use:

Installation:

Restricted area

The room in which this sign is posted is defined as a restricted laser area:

- in normal production phase (1)
- maintenance and setting phase (1)
-(1)

Regulation in the restricted area

Access to the restricted laser area is regulated. Only competent personnel having attended proper training can remain during the operation: this implies medical aptitude and laser safety training.

Any person authorized access to the restricted area is to observe the rules provided by the employer.

(1) To be filled in or crossed out.

Laser safety

■ General Instructions



- **Avoid any exposure to laser radiation.**
- **Do not put hands or an object in the laser beam's trajectory.**
- **Never stare into the primary laser beam.**
- **Avoid direct eye exposure to diode laser beam.**
- **Do not direct the beam towards other persons, openings or windows.**
- **Do not remove protection hoods or short-circuit the securities.**
- **Electrical interventions on the system can only be carried out by competent LT/HT personnel.**
- **In the event of an incident or even doubts concerning the functioning of the installation, inform the person in charge of laser safety.**

■ Wearing safety glasses

Under normal conditions of use, the machine operates at Class 1 - 2M: protective goggles are not necessary.

Laser radiation safety glasses are mandatory whenever in an area where laser radiation emission exceeds class 3B AEL.

As a user, it is mandatory to declare the use of class 4 laser station to current authorities and to follow their safety recommendations.

Name and address of the doctor in charge of medical exams for personnel occupying the laser restricted area:

..... Tel:.....


Name and address of person in charge of the observance of laser security regulation in the restricted area:

..... Tel:.....

Laser safety

4. Potential hazards related to materials worked with

■ Fumes and toxic particles

	<p>Laser marking certain materials emits dangerous fumes and particles that may be toxic and/or damage the equipment.</p> <p>In this case, adapt an extraction system (with filtration if necessary) to the marking station.</p>
---	--

The processing of parts using this type of Laser causes thermal and photo-electric (molecular) deterioration of the material. Even micro-quantities of the by-product (soot or fumes), created during Laser marking, may accumulate over a long period. Some of these by-products may prove to be hazardous to humans.

Health side-effects to the operators may include poisoning, allergies or cancer. Here are some examples of the most sensitive materials:

- plastics and rubber
- painted materials
- anodized and galvanized metals
- ceramics
- materials containing lead or mercury

For a more detailed list of the risks related to the material worked with, consult Annex A of the ISO 11553- 1:2005 standard.

In this case, adapt an extraction system (with filtration if necessary) to the marking station. This system vacuums chips from the marking area.

It must be linked to:

- either a centralised vacuum system with an external evacuation.
- either an independent system dedicated to the marking station, which removes fumes and particles using activated carbon filters.

The user must observe national legislation in force concerning chemical agent exposure limits.

For more information, contact us.

Laser safety

■ Examples of secondary radiation risks

The use of a class 4 laser device can generate:

- A risk of fire or explosion due to materials or inflammable substances
- UV radiation
- X rays
- High intensity visible light when marking on certain materials


■ Reflected beam

Special integration is required when marking some materials to prevent the beam reflecting.

- Copper, copper-based materials (bronze, brass)
- Gold
- Silver
- Polished materials

H. Description of the machine


■ Global view of the marking area



1. Door
2. Laser protection glass
3. Motorized Z-axis
4. Mount: marking head
5. Marking area lighting
6. Color touch screen
7. Support feet

I. Color touch screen

Piloting via an internal program




The window appears when the tablet is started up.

To confirm, press the key: Confirm and move.


The laser is reset. The door moves to its origin.

Axis origin set: Press.  (press and hold - 3 s).



Color touch screen

1. Main screen



1. Main menu
2. Start marking
3. Stop marking
4. Door opening/closing
5. CCU information
6. Z-axis raising / Z-axis lowering
7. Edit: head positioning: Z
8. Date/Time
9. Absolute distance / Reference value
10. Door opening/closing: Automatic mode

■ Main menu

Icon used to return to the main menu, followed by the name of the menu. This icon appears several times in the program.

■ Start marking

Used to start marking.

The indicator light signals that the marking file is ready for marking.

Green light: Marking in progress

■ Stop marking

Used to stop the marking cycle at any time.

Color touch screen

■ Door opening/closing

When not in automatic mode, pressing once on the button causes the door to change status.

Do not hold the button down.

In automatic mode, the button is disabled.

■ Z axis

The motorized Z axis is controlled via the touch screen.



: Absolute distance / Reference value

Display of the position of the Z axis in relation to absolute 0. Absolute 0 corresponds to the highest point on the axis.

The reference value allows the user to define a new origin. It corresponds to the focal distance.

Axis origin set: press and hold - 3 s



Edit: head positioning: Z



: Z-axis raising / Z-axis lowering

Used to raise or lower the marking head in order to adjust focus.


Pressing the button once causes a movement of 0.2 mm (0.008 in).

Color touch screen

■ Door opening/closing: Automatic mode

Click on: .

The screen below appears:



1. *Indicator lights on*

Automatic mode must be activated when the door is open.

Marking time must exceed 1 second.

The indicator light signals whether automatic mode is activated.

When marking is started, the door closes, marking is executed and the door opens at the end of the cycle.

Automatic mode is compatible with marking management modes (independent, infinite, N times, etc.)

It is essential to start marking with the touch screen.


It is no longer possible to use the raise and lower buttons.

It is no longer possible to modify the position of the Z axis.

Color touch screen

2. Marking parameters

■ Configuration: Command



1. *Marking parameters*
2. *Command*
3. *Network configuration*
4. *Adjustment*
5. *System information*
6. *Update / Backup/restore data*
7. *"Safety circuit reset" button*
8. *Activation/deactivation of the extractor*
9. *Marking area lighting (On/Off)*

- **Safety circuit reset**

Switching on the laser source following start-up or an emergency stoppage of the machine.

- **Fume extraction - filtration**

Used to activate/deactivate the fume extraction and filtration system.

This function is only available with model ES10-ES30.


- **Marking area lighting**

Switches the marking field lighting on or off.

Color touch screen

■ Network configuration

Allows the machine's network connection to be set up. The screen below appears:




1. Network configuration
2. DHCP mode
3. Port number
4. "Check" key
5. Gateway
6. Subnet mask
7. IP address

When DHCP mode is selected, an IP address and a subnet mask are automatically assigned.


Color touch screen

■ Adjustment



1. Activate screen calibration
2. Adjustment
3. Date
4. "Check" key
5. Time
6. Brightness
7. Activation of the buzzer
8. Units (mm or inches)

■ System information




This menu contains technical information that can be communicated to the distributor or the technical support in case of problem.


Color touch screen

■ Update


Insert the USB key into the LW2 Touch. File imports and updates are performed via USB key.



1. Selecting the update file



Select the file.




Color touch screen




To confirm, press the key:

- **Backup: Memory backup**


Used to backup all the data to a single file.



1. Press the key: Backup




Color touch screen



The file created in this way may be saved to a USB key but may not be opened.


- **Restore: Data recovery**

Used to restore all the data previously backed up.



1. Press the key: Restore


Select the file.



Color touch screen

3. "File" menu

■ Marking file



■ Logos

List of available logos (in the marking file(s)):



Color touch screen

■ Fonts


List of available fonts (in the marking file(s)):



■ USB connection


Connect the USB key to the machine. File imports and updates are performed via USB key.

List of marking files:



Color touch screen

4. "Variables" menu



Variable	Value
V0	1414
V1	GRAVOTECH
V2	AB123
V3	31415
V4	1337
V5	2718
V6	
V7	
V8	
V9	

Allows the user to modify the content of the variables in the marking files.


The PC can be disconnected.

5. Menu: Security mode

■ "Supervisor" mode

This mode is selected by default.

Used to limit access to certain functions in the program. Switching from one operating mode to another is password protected. This password can only be changed under the "Supervisor" operating mode.




User selection


☐ Operator ☒ Supervisor ☐ Technician

Color touch screen


Setting the password: click on: Change password.



The screenshot shows a touch screen interface with a grey header bar containing icons for home, settings, documents, a 'V' logo, and a group of people. The time and date '09:23 20 May 2019' are in the top right. Below the header, a 'User selection' section has three radio buttons: 'Operator', 'Supervisor' (which is checked), and 'Technician'. Below this, the text 'Please enter supervisor password' is followed by a 'Password' label and a single text input field. At the bottom right of this section are two buttons: 'Change password' and 'Valid'.



This screenshot shows the same interface as the previous one, but the text now says 'Please enter new supervisor password'. It includes three text input fields labeled 'Old password', 'Password', and 'Confirm password'. A 'Valid' button is located at the bottom right.




The screenshot shows the same interface, but the 'Valid' button is no longer present. Instead, the text 'Mode successfully changed to supervisor.' is displayed in the main area of the screen.

Color touch screen

■ "Operator" mode

Select either "Supervisor" or "Operator" mode for the operating mode of the program.




Functions accessible in "Operator" mode:


- Main menu:
 - Start marking
 - Stop marking
 - Door opening/closing
 - Door opening/closing (Automatic mode)
 - CCU information
 - Absolute distance / Reference value
 - Z-axis raising / Z-axis lowering
 - Edit: Head positioning: Z
 - Date/Time

Color touch screen

- Marking parameters




1. Command
2. System information
3. Saving parameters



1. "Safety circuit reset" button
2. Activation/deactivation of the extractor
3. Marking area lighting (On/Off)

Color touch screen


- "File" menu



1. Loading the marking files
2. File simulation

The operator cannot delete the files.

System information:





Color touch screen

- "Variables" menu
 - Set variable

■ Technician mode

This option is password protected.

Configuration - Firmware: only an approved technician is authorised to carry out this operation.



1. Technician mode
2. Program management
3. Menu: Diagnosis
4. Menu: Inputs / Outputs


Color touch screen

6. Emergency stop

Pull on the emergency stop button in order to deactivate it.

Follow the instructions on the screen.



Click on "OK".



- Safety circuit reset:




Click on the icon:



Click on the icon:

Color touch screen


- Fault acknowledgement: click on the icon:



- Return to origin: click on the icon:  (press and hold: 3 s).

The head goes back to the origin.

To go back to the main menu or to the last screen, press the corresponding icon:



The machine is ready for operation.

J. Installation

1. Electrical installation



Turn off the machine before beginning any cleaning, maintenance or repair procedure. Always switch the machine off before connecting or disconnecting a cable or optional accessory.

Never unplug a cable while the machine is turned on (except for the mains lead in the event of an emergency). The power outlet must be located alongside the equipment and must be easily accessible.

Do not remove the power supply cover: risk of electric shock.

The connection to the single phase power supply is made with a standard, 3 pin plug with grounding. Grounding must be done according to the regulations in effect to ensure the safety of the personnel.

2. Physical installation




The different elements of the equipment must be connected with the power off. The power supply should be connected last.

To install the equipment in complete safety, follow the stages below.


■ Step 1: Opening the casing

1. **Unscrew the 4 screws at the top of the housing.**




Installation


2. Tilt the cover forward slightly.




3. Raise the cover by approximately 10 mm (0.394 in) by pulling it towards the rear in order to free up space at the front, between the cover and the door.



4. Tilt the cover until vertical.





5. Lift off the cover, pressing its sides lightly.



Installation

■ Step 2


Remove 2 screws CHC M5x45 in order to release the counterweights. Retain the screws for any future shipping operation (maintenance, after-sale service, etc.)



3. Fiber series (+ Energy)


■ Step 3

1. Remove the screws (x4).



Installation

2. Open the flange at the back.



If there is already a laser in the machine:

1. Remove the screws (x4):




2. Open the flange at the back.



Installation

■ Step 4


1. Place the laser in the LW2 Touch, on its support (Z axis).



2. Use the screws provided to attach the marking head to the frame designed for this purpose.



Do not touch the other screws in the marking head.



Installation


■ Step 5: Optical head connection




Never hold or manipulate the optical head by the fiber.

Always use the aluminium isolator mount to manipulate.

1. Insert the optical head in the marking head and fasten with the 3 M5 screws supplied (3D lens: Mount with the 2 screws).



2. Mount the 2 flanges using the 6 M5 screws provided.



Installation


■ Step 6: Connection of the marking head to the CCU



Do not touch the other screws in the optical head.

See below.

Marking head - View of connectors



1. 17 point connector - Head/CCU connecting cable
2. 19 point connector - Head/CCU connecting cable
3. Optical head

1. Connect the 17 point connector.


2. Connect the 19 point connector.

Do not touch the optical head.

3. Installing the laser module.

Installation

Fit the protection caps (supplied with the machine).



Protection cap(s)




No light must be allowed to pass between the flange, the laser and the cables.

4. Re-close and lock the upper flange.



If closing the flange is difficult, unplug the laser connectors or tighten the flanges using locking pliers, protecting the bellows (thick plastic or cardboard).

5. Close the housing (reverse of the disassembly operation).




Installation

4. Hybrid - Green - CO2 Energy series


■ Step 3

1. Remove the screws (x4).



Open the flange at the back. Remove the laser, if present.


Remove the closing plate at the back of the machine to install the Laser module.



Installation


■ Step 4

1. Place the laser in the LW2 Touch, on its support (Z axis).



2. Reclose and lock the flange.


No light must be allowed to pass between the flange, the laser and the cables.



3. Use the screws provided to attach the marking head to the frame designed for this purpose.




Do not touch the other screws in the marking head.



Installation

4. Close the housing (reverse of the disassembly operation).




K. Connections - Installation

1. Connecting the Control Unit (Fiber series (+ Energy))



The different elements of the equipment must be connected with the power off. The power supply should be connected last.


Control Unit - LW2 Touch: View of connectors




1. 19 point connector Head/CCU connecting cable (cable supplied): Marking-head signals
2. 17 point connector Head/CCU connecting cable (cable supplied): X-Y signals
3. Profinet/Ethernet IP module (optional)
4. 7 point connector (DIN F) - Not available
5. 3 point connector (DIN F) - Not available
6. DB15F connector
7. Ethernet connection (RJ45)
8. I/O connector (screw terminal block)
9. RS232 link (DB9M)
10. Port: USB-B
11. DB37F: Dedicated Inputs/Outputs
12. Port: USB-A (x2)
13. Fuse
14. 110 - 230 V AC / 10 A power connection (cable supplied)
15. Optical fiber
16. Air outlet
17. Autofocus connector

Connections - Installation

- Connection of the marking head to the CCU
 1. Connect the marking head to the CCU with the two connection cables provided (17 points - 19 points).
 2. Push the connectors into the socket and tighten the locking rings.
 3. Make sure the connection is correct.
- Connection to DB37M connector (Ref: 54260)



- Connection to DB37F connector (Ref: 50875)



- Connection USB



Connections - Installation


- Connection: Tablet



- Connection RD1/RD2 (optional)




Cable + flange kit



Connections - Installation


- Fume extractor connection: ES30 (optional)
1. The different elements of the equipment must be connected with the power off. The power supply should be connected last.
 2. Remove the cover.




3. Attach the exhaust tube adapter.



4. Connect the tube to the LW2 Touch (diameter 100). Tighten the hose clamp.



5. Connect the tube to the extractor (diameter 100). Tighten the hose clamp.




Connections - Installation

6. Connect the cable ES30 / LW2 Touch.



- Power supply connection



Connections - Installation

2. Installation

■ Possible integration and operating positions for the Fiber Series (+Energy)

Position the Control Unit horizontally, in a dry, ventilated area, at least 20 cm (7.874 in) from the floor. Always leave a free space of 50 mm (1.969 in) in front of the CCU and of 150 mm (5.906 in) in back for good air circulation. As components are air-cooled, air circulation in the CCU must not be perturbed.

Version rack 19" 4U-5U: used to integrate the CCU in a cabinet. Vertical position possible



Analyse the CCU's integration in order to avoid problems due to the fiber's minimum bend radius.


■ Possible integration and operating positions for the Hybrid - Green - CO2 Energy Series

We recommend the horizontal position, with the laser beam directed downwards.



Clean the protective glass regularly to prevent loss of power and deterioration of the marking quality. It must be cleaned with an appropriate lens paper using acetone.

Position the machine at a distance of at least 150 mm (5.906 in) from the wall.



Connections - Installation

■ Laser startup

See the user manual of the machine.




The shutter closes automatically when the door opens and it opens automatically when the door closes. The marking can only be carried out if the door is closed.

When the machine is working in Class 1 - 2M protective goggles are not obligatory.

■ Emergency stop

In case of emergency, press on the CCU or LW2 Touch's emergency stop button.








Emergency stop push button

L. Accessories available upon request


Please give the item codes with your order to speed processing.

1. List of accessories and options available upon request



Reference	Description	
77650 (Hybrid Energy Series) 78636 (Fiber Series (+Energy))	3D module Built-in system mounted in factory Used to mark at different distances without the need to refocus. - +/- 30 mm (1.181 in) (F160) - +/- 60 mm (2.362 in) (F254)	
78272 (Hybrid - Green - CO2 Energy Series) 78853 (Fiber Series (+Energy))	Autofocus Automatic focus adjustment (automatic Z Ref.) The kit comprises: - distance sensor - head/CCU connecting cable (3 m (9.842 ft)) This option must be used with the 3D module.	
77787 77789	- Focusing diode (Hybrid - Fiber Series (+ Energy)) - Focusing diode (Green Energy Series)	
78389	Extension for the focusing diode - Focusing diode not included Order references for the various options separately.	
79080	Fume extraction - filtration (adapter) The kit comprises: - Adaptor for the fume extraction system - Fume extraction - filtration	

Accessories available upon request



■ Rotary device

Reference	Description	
79251	RD1 - Marking small to medium diameter cylinders - Key chuck Diameter: 3 mm (0.118 in) - 98 mm (3.858 in) For more information, consult the manual of the machine in question.	
79252	RD2 - Marking small to large diameter cylinders - Key chuck Diameter: 3 mm (0.118 in) - 152 mm (5.984 in) For more information, consult the manual of the machine in question.	
79253	RDM - Manual chuck - Easy to manipulate Diameter: 4 mm (0.157 in) - 129 mm (5.079 in) For more information, consult the manual of the machine in question.	
TBC	RD Jewel	




■ Work station safety

Reference	Description	
75038	Extra pair of glasses (DIR LB6 - 532 nm -1064 nm) (Hybrid - Green Energy Series) It is mandatory that the operator wear eye protection with the suitable filter lenses.	
75741	Extra pair of glasses (DIR LB6 - 10600 nm) (CO2 Energy Series) It is mandatory that the operator wear eye protection with the suitable filter lenses.	

Accessories available upon request

Reference	Description	
60995 60996 60997 60998 76287	<p>ES10: Fume extractor for small applications, in the case of occasional marking (marking on plastic)</p> <p>Connecting cable(s): Laser fume extractor (ES10) / Hybrid-Green - CO2 - Fiber Series (+ Energy)</p> <p>- 230 V (UE) - 230 V (UK) - 230 V (CH) - 115 V (US) - 230 V (CN)</p>	
69835 69836 69837 69838 76288	<p>ES30: Fume extractor for applications of medium size, in the case of continuous marking (marking on plastic)</p> <p>Connecting cable(s): Laser fume extractor (ES30) / Hybrid-Green - CO2 - Fiber Series (+ Energy)</p> <p>- 230 V (UE) - 230 V (UK) - 230 V (CH) - 115 V (US) - 230 V (CN)</p>	

■ Other accessories

Reference	Description	
60287 D16206	<p>Button box for start / stop cycle:</p> <p>- Emergency stop - Start marking - Stop marking</p>	
26327	Optical cleaning kit	
66254	<p>EZ-FIX</p> <p>Used to rapidly fix small objects or items with various shapes.</p>	

Accessories available upon request

2. Wearing and spare parts

■ Spare parts


Reference	Description
81949	Color touch screen
TBC	Kit: support feet
54260	CCU/LW2 Touch connection cable (37 point connector)

■ Wearing parts

Reference	Description
66539	Door seal
69908	Microswitch kit (1 microswitch + fastenings)

M.Preventive maintenance

1. Visual inspection of the bellows (rear of LW2 Touch)



- 1. *Upper bellows*
- 2. *Lower bellows*



Check the condition of the bellows in the event of burning or perforation.

Preventive maintenance

2. Every year

(Or in the event of noise emanating from the Z axis screw)

1. **Raise the bellows.**
2. **Re-lubricate the Z axis screw using the grease pack supplied.**

■ Cleaning the sensors

The Z axis is equipped with a sensor to detect the end of travel along Z.


This optoelectronic fork sensor indicates the presence of the 2 carriages at the origin.

Certain exterior elements (chips, shavings...) can get stuck between the sensors and disrupt their functioning.

To remove these foreign objects, use an air gun to direct a shot of air between the sensor.

N. Dimensional drawings

1. LW2 Touch dimensional drawing




1. 4 support feet (adjustable)
2. Laser protection glass: 180 mm (7.087 in) x 280 mm (11.024 in)
3. Color touch screen
4. Mount (color touch screen)
5. Cover
6. M6 packing bolts (x4)
7. Door
8. Control interface board
9. Mobile protective shutters
10. Connection: Suction hose (optional)
11. Handles (x6): Handling the machine
12. Cable transit
13. Fuse carrier
14. SUBD37F - Input
15. Port: USB (Control Unit)
16. Fume extractor connection
17. SUBD37M - Output
18. Port: USB
19. SUBD25F - Color touch screen

Weight: 60 kg (132.277 lb)

Dimensional drawings

2. Fiber - Hybrid - Green - CO2 Energy Series

■ LW2 Touch dimensional drawing




1. Optical fiber axis
2. Z axis (Travel distance 295 mm (11.614 in))
3. Marking area: 100/160/254/330 Focal lens


Weight: 69 kg (152.119 lb) (LW2 touch + Fiber series (+ Energy) marking head)

Dimensional drawings

■ Dimensional drawing of the table



1. Marking area: 205 mm (8.071 in) x 205 mm (8.071 in)
2. Marking area: 175 mm (6.890 in) x 175 mm (6.890 in)
3. Marking area: 110 mm (4.331 in) x 110 mm (4.331 in)
4. Handles (x4)
5. Marking area: 65 mm (2.559 in) x 65 mm (2.559 in)
6. 27 fastening holes (M6)
7. Origin



Dimensional drawings

3. Max height of the part to be marked

■ 100 Focal lens

Fiber Series (+ Energy)	Hybrid Energy Series	Green Energy Series	CO2 Energy Series
345 mm (13.583 in)	-	-	-

■ 160 Focal lens

Fiber Series (+ Energy)	Hybrid Energy Series	Green Energy Series	CO2 Energy Series
160 Focal lens: 255 mm (10.039 in) F20 Energy: 261 mm (10.276 in)	160 Focal lens: 216 mm (8.504 in)	165 Focal lens: 219 mm (8.622 in)	150 Focal lens: 337 mm (13.268 in)

■ 254 Focal lens

Fiber Series (+ Energy)	Hybrid Energy Series	Green Energy Series	CO2 Energy Series
159 mm (6.260 in)	122 mm (4.803 in)	122 mm (4.803 in)	200 Focal lens: 262 mm (10.315 in)

■ 330 Focal lens

Fiber Series (+ Energy)	Hybrid Energy Series	Green Energy Series	CO2 Energy Series
42 mm (1.654 in)	-	-	-

These values are approximative. Distances may vary approximately +/- 20 mm (0.787 in) depending on the laser's and focal lens' specific characteristics.

Max height of the part to be marked = Maximum distance between the marking head and the table (fixed value: 442 mm (17.402 in)) - Focal distance - Tolerance

Example: LW2 Touch + F20 Energy (160 Focal lens):

442 mm (17.402 in) - 176 mm (6.929 in) - 5 mm (0.197 in) = 261 mm (10.276 in)

O. Noise emission of the machine

1. Test code

■ Measurement method

The measurements were taken according to the regulations of standard ISO 12001:1996.

■ Material used for marking:

- Machine: LW2 Touch + Fiber Energy Series 20 W
- One electronic command unit
- An interface computer (used by the operator)

■ Definition of the microphone position

The microphone is positioned 1 m (3.281 ft) in front of the machine and 1.4 m (4.593 ft) from the floor.

The measurements were taken according to the regulations of standard ISO 12001:1996.

■ Test conditions

- Marking speed: 100 mm/s
- Power: 100%
- Frequency: 30 kHz
- Marking of 3 lines of 10 characters 5 mm (0.197 in) high
- Steel plate with dimensions 110 mm (4.331 in) x 100 mm (3.937 in) x 3 mm (0.118 in)

2. Noise emission information

The equivalent continuous sound level A (L_{Aeq}) is below 70 dB(A).

P. Technical specifications

1. Physical characteristics

Dimensions (L x w x h): Machine	600 mm (23.622 in) x 622 mm (24.488 in) x 772 mm (30.394 in)
Dimensions (L x w x h): Laser protection glass	180 mm (7.087 in) x 280 mm (11.024 in)
Net weight: Machine (no accessories)	60 kg (132.277 lb)
Dimensions (L x D x H): With packaging	778 mm (30.630 in) x 764 mm (30.079 in) x 985 mm (38.779 in)
Weight: With packaging	66 kg (145.505 lb)
Object to be engraved: Dimensions	502 mm (19.764 in) x 477 mm (18.779 in) x 322 mm (12.677 in) (according on the lens used) (Maximum)
Motorized Z-axis: Travel distance Z	295 mm (11.614 in)
Classification	Class 1 (EN 60825-1 standard)

- Marking area

100 Focal lens	160 Focal lens	254 Focal lens	330 Focal lens
65 mm (2.559 in) x 65 mm (2.559 in)	110 mm (4.331 in) x 110 mm (4.331 in)	175 mm (6.890 in) x 175 mm (6.890 in)	205 mm (8.071 in) x 205 mm (8.071 in)

CO₂:

150 Focal lens	200 Focal lens
100 mm (3.937 in) x 100 mm (3.937 in)	140 mm (5.512 in) x 140 mm (5.512 in)

- Safety door

Force exerted on the human body	35 N
Kinetic energy of the mobile part	0.3 J
Contact pressure	5 N/cm ²

Technical specifications

2. Electrical characteristics

Nominal voltage	100 - 240 V AC
Frequency	50 / 60 Hz
Power	800 W
Electrical protection by fuse	6.3 A --> Voltage: 115 V 3.15 A --> Voltage: 230 V
Phases	1

3. Environment

Operating temperature	15 °C (59 °F) - 35 °C (95 °F)
Storage temperature	10 °C (50 °F) - 40 °C (104 °F)
Humidity level	20 - 80%

4. Laser beam

- Class 4 (EN60825-1) (class 1 with suitable protection)

	Fiber Series	Fiber Energy Series	Hybrid Energy Series	Green Energy Series	CO2 Energy Series
Wavelength	1064 nm	1064 nm	1064 nm	532 nm	10 600 nm
Power	20 - 30 - 50 W	20 W	10/20 W	5 W	20/30 W
Minimum pulse duration	100 ns	100 ns	5 ns	5 ns	CW
Frequency	F20: 20 kHz - 100 kHz F30: 30 kHz - 100 kHz F50: 50 kHz - 200 kHz	30 kHz - 60 kHz	10 kHz - 100 kHz	10 kHz - 100 kHz	CW

5. Aiming diode - Focusing diode

Power	Maximum: 1 mW
Wavelength	650 nm
Classification	Class 2M (EN 60825-1 standard)

Technical specifications

6. Material

		Fiber Series (+ Energy) 20 - 30 - 50 W	Hybrid Energy Series 10 - 20 W	Green Energy Series 5 W	CO2 Energy Series 20 - 30 W
Metal support	Steel, stainless steel	O	O	X	X
	Aluminium	O	O	X	X
	Carbide	O	O	O	X
	Copper, brass	O	O	X	X
	Titanium	O	X	X	X
	Gold, silver, nickel, platinum	X	O	O	X
Plastic	ABS	O	O	O	X
	Polyamide (PA)	O	O	O	X
	PC	X	O	O	X
	PE - PET	X	X	O	X
	POM - PBT	O	O	O	X
	PP	X	X	O	X
Organic material	Wood, varnished wood	X	X	X	O
	Rubber	X	X	X	O
	Leather	X	X	X	O
	Paper, cardboard, cork	X	X	X	O
	Stone, marble, granite	X	X	X	O
Others	Terracotta	X	X	X	O
	Ceramics (applications: electric, medical)	O	O	O	X
	Silicone	X	X	O	O
	Glass, crystal	X	X	X	O

O = Marking: contrasting

X = Marking: non-contrasting